

DOCUMENT RESUME

ED 221 396

SE 039 208

AUTHOR Wooley, John F.
TITLE Oxygen Uptake. Operational Control Tests for Wastewater Treatment Facilities. Instructor's Manual [and] Student Workbook.
INSTITUTION Linn-Benton Community Coll., Albany, Oreg.
SPONS AGENCY Office of Water Program Operations (EPA), Cincinnati, Ohio. National Training and Operational Technology Center.
PUB DATE Sep 81
GRANT EPA-900953010
NOTE 67p.; Slide/tape program which accompanies this module is also available from Linn-Benton Community College.
AVAILABLE FROM Linn-Benton Community College, 6500 S.W. Pacific Blvd., Albany, OR 97321 (\$1. student workbook, \$2. instructor's guide).
EDRS PRICE MF01 Plus Postage. PC Not Available from EDRS.
DESCRIPTORS Instructional Materials; *Laboratory Procedures; Microbiology; Postsecondary Education; *Sludge; Teaching Guides; *Training Methods; *Waste Water; Water Quality; *Water Treatment
IDENTIFIERS Oxygen Uptake Test

ABSTRACT

Biological waste treatment in the activated sludge process is based on the ability of microorganisms to use dissolved oxygen in breaking down soluble organic substances. The oxygen uptake test is a means of measuring the respiration rate of microorganisms in this process. Designed for individuals who have completed National Pollutant Discharge Elimination System (NPDES) level 1 laboratory training skills, this module provides waste water treatment plant operators with the basic skills and information needed to: (1) successfully run the oxygen uptake test; (2) graph its results; (3) properly perform calculations for slope, oxygen uptake rates, and specific uptake rates; and (4) obtain reliable data from the test procedure. The instructor's manual contains a statement of instructional goals, lists of instructor/student activities and instructional materials, narrative of the slide/tape program used with the module, overhead transparency masters, and student worksheet (with answers). The student workbook contains objectives, prerequisite skills needed before the module is started, sources of dissolved oxygen meters, laboratory procedures (oxygen uptake test, stabilization test, suspended solids, and volatile suspended solids), and worksheet. (Author/JN)

* Reproductions supplied by EDRS are the best that can be made *
* from the original document. *

Operational Control Tests for Wastewater Treatment Facilities

U.S. DEPARTMENT OF EDUCATION
NATIONAL INSTITUTE OF EDUCATION
EDUCATIONAL RESOURCES INFORMATION
CENTER (ERIC)


This document has been reproduced as
received from the person or organization
originating it.

Minor changes have been made to improve
reproduction quality.

- Points of view or opinions stated in this docu-
ment do not necessarily represent official NIE
position or policy.

Oxygen Uptake


Instructor's Manual



"PERMISSION TO REPRODUCE THIS
MATERIAL IN MICROFICHE ONLY
HAS BEEN GRANTED BY

John W. Carnegie

TO THE EDUCATIONAL RESOURCES
INFORMATION CENTER (ERIC)."



Linn-Benton Community College
Albany, Oregon

ED0221396

SE039208

OXYGEN UPTAKE

Written By:
John F. Wooley
Linn-Benton Community College
Albany, Oregon

Instructional Design:
Priscilla Hardin
Corvallis, Oregon

Project Management
John W. Carnegie, Ph.D.
Linn-Benton Community College
Albany, Oregon

Project Officer:
Lynn S. Marshall
United States Environmental Protection Agency
National Training and Operational Technology Center
Cincinnati, Ohio

Developed Under:
EPA Grant #900953010
August, 1980

OXYGEN UPTAKE TEST

<u>Subject</u>	<u>Page</u>
Instructional Goals	Ou-1
Instructor Activity	Ou-1
Student Activity	Ou-2
Instructional Materials List	Ou-2
Narrative	Ou-3
Appendix A	Ou-9
Appendix B	Ou-13
Appendix C	Ou-15
Appendix D	Ou-18
Appendix E	Ou-20
Answers to Worksheet	W-Ou-1
Student Materials	S-Ou-1 thru 21
	SW-Ou-1 thru 5

INSTRUCTIONAL GOALS

Upon completion of this module the student should be able to successfully run the oxygen uptake test, graph its results, and properly perform calculations for slope, oxygen uptake rates and specific uptake rates.

INSTRUCTOR'S ACTIVITIES

The following sequence is recommended for best use of this material:

<u>Activity</u>	<u>Time</u>
1. Review objectives with students.	5 minutes
2. Have students read through the procedure.	10 minutes
3. View and listen to the slide/tape program.	18 minutes
4. Discuss concept of slope, slope calculations, relationship of slope to oxygen uptake, and specific uptake.	20 minutes
5. Demonstrate the procedure.	15 minutes
6. Assign the worksheet.	15 minutes
7. Correct the worksheet.	5 minutes
8. Have students perform the test.	35 minutes

OTHER ACTIVITIES

The above sequence should be followed if there is ample time. If time is short and if the students have already developed and displayed good laboratory proficiencies the demonstration may be omitted. Items to emphasize during the demonstration should include:

1. Calibration of DO meters, including check of membrane.
2. Mixing of sample.
3. Check for adequate seal between stopper and flask.
4. Plotting of DO depletions against time.
5. Allowing sufficient time in the test to allow at least 1 mg/l DO depletion from beginning to end of the test.

Calculations can be discussed using the overhead in Appendix A to show different oxygen concentrations in a plot of depletions vs time. Two points in time are selected through which the plotted line passes. By subtracting the lower DO value from the high DO value and dividing that answer by the

the lower DO value from the higher DO value and dividing that answer by the time intervals between the selected points, the slope is obtained.

The overheads in Appendix B can be used to describe the calculation of uptake rate. The uptake rate is expressed normally in mg O₂/l/hr. Since slope is expressed as mg O₂/l/min., we must convert oxygen values per minute to oxygen values per hour.

Appendix C contains overheads that describe the calculation of specific uptake rates. The SUR is the uptake rate in mg O₂/l/hr multiplied by a factor to convert mg/l MLVSS to g/l MLVSS. This is necessary as units on the SUR value are expressed as mg/l O₂/l/hr/g MLVSS.

$$S.U.R. = \frac{U.R. \times 1000}{mg/l \text{ MLVSS}}$$

Using different values for U.R. and MLVSS, have the students calculate the SUR. For more information on oxygen uptake see:

1. Activated Sludge Operational Control, by Environmental Technology Department, Linn-Benton Community College, Albany, Oregon 97321.

STUDENT ACTIVITIES

1. Read objectives.
2. Read procedures.
3. View slide program.
4. Complete worksheet.
5. Perform test.
6. Record data.
7. Perform calculations.

INSTRUCTIONAL MATERIALS LIST

1. Instructors Guide for Oxygen Uptake
2. Students Workbook for Oxygen Uptake
3. 35mm projector
4. Cassette tape player with automatic synchronization
5. Projector screen
6. Overhead screen
7. Equipment needed for Oxygen Uptake Test.

OXYGEN UPTAKE TEST

NARRATIVE

Slide

1. This lesson describes the Oxygen Uptake Analysis and its use in measuring the metabolic activity of organisms in aquatic systems. Theory, procedure and application are also covered.
2. The lesson was written by John F. Wooley and Dr. John W. Carnegie. Dr. Carnegie was also the project manager. Priscilla Hardin provided instructional design and art work.
3. Microorganisms use oxygen as they consume food in an aerobic aquatic system. The rate at which they use oxygen is an indicator of the biological activity of the system and is called the Oxygen Uptake Rate.
4. High oxygen uptake rates indicate high biological activity; low oxygen uptake rates indicate low biological activity.
5. In biological waste treatment facilities oxygen uptake rates are used to monitor performance of process units.
6. The oxygen uptake rate is based on a series of dissolved oxygen measurements taken on a sample over a period of time.
7. The oxygen uptake test is most valuable for plant operations when combined with volatile suspended solids data.
8. Combining oxygen uptake and volatile suspended solids data yields a value called Specific Uptake Rate.
9. Specific uptake rates describe the amount of oxygen used by the microorganisms to consume one gram of food. The specific uptake rate is reported as mg/l of oxygen used per gram of organic material per hour.
10. The specific uptake rate is valuable when comparing one aquatic system with another. The performance of one aeration basin can be compared with another or the biological activity in a stream can be studied and compared both above and below a waste outfall.
11. Equipment needed for the oxygen uptake test includes: a timer, a DO meter with submersible stirrer and temperature probe, a 300 ml BOD bottle, a magnetic stirrer with stirring bar, and a sample container. You will also need to assemble the equipment to run a volatile suspended solids test.

12. The basic oxygen uptake procedure includes 5 basic components: the collection and preparation of sample, the procedure of oxygen uptake analysis itself, the data recording, cleaning, and calculation of oxygen uptake rate. To calculate the specific uptake rate, combine the oxygen uptake rate with volatile suspended solids data.
13. Let's focus on each of these components. First is the collection and preparation of the sample. Sample collection involves four steps. First, select the sample site. Next, measure the water temperature and the dissolved oxygen concentration. Then collect a sample for analysis in the laboratory.
14. As soon as it arrives in the lab, split the sample. One portion is used in the oxygen uptake test, the other in the volatile suspended solids test. The procedures for running VSS are not covered in these materials. (Refer to the Appendix of the manual for VSS information.)
15. Sample site selection is extremely important. A poorly selected sample site, whether in an aquatic stream survey or in a wastewater treatment plant, will always produce poor data.
16. For activated sludge operations a grab sample on the aeration basin effluent prior to secondary clarification provides useful data. We will use a grab sample to illustrate the oxygen uptake procedure. Then we will look at a couple of useful variations of sample collection and preparation.
17. After the sample site has been determined, DO and temperature measurements are made at that point. These data are recorded for reference later when interpreting the results of the oxygen uptake test.
18. The two liters of sample are collected in a clean sample container. An important point to remember is that air space must be provided in the sample container. DO NOT OVER FILL!
19. This sample should be taken immediately to the lab for analysis. DO NOT STORE.
20. The purpose of immediate analysis of the sample is to prevent changes in its composition. Living organisms will continue their life processes and in doing so will change the make-up of the sample.
21. In the lab, the sample is split. At least one liter is required for the oxygen uptake test, the remainder is available for the volatile suspended solids test.
22. The procedure for Oxygen Uptake Analysis requires four basic stages. First the sample is mixed. Then, it is poured into a 300 ml BOD bottle. Next, the BOD bottle is fitted with a DO probe and placed on a stirrer. In the last stage, the meter and timer are turned on and the DO concentrations are read and recorded at one minute intervals.

23. Stage one requires that the sample be thoroughly mixed.
24. Immediately pour the sample into the 300 ml BOD bottle. Fill the bottle completely.
25. Place a PVC adapter in the BOD bottle and connect a second bottle to the first. Pour back and forth several times to insure complete mixing and aeration.
26. Put the magnetic stirring bar into the bottle and place the DO probe into the bottle's neck. Make sure the probe provides a good seal and that it is immersed in the sample.
27. Place the BOD bottle on the magnetic stirrer and turn it on.
28. Measure and record the DO concentration in the BOD bottle every minute for at least ten minutes.
29. The exact time required depends on the rate at which oxygen is used. Allow sufficient time to get at least one mg/l DO difference between the start and finish of the test.
30. After the measurements have been made and recorded the BOD bottle should be emptied and thoroughly rinsed. Any remaining sample in the sample container can be discarded and the container cleaned for future use.
31. Before proceeding with the calculations on the grab sample let's look at sample preparation for 2 additional applications of the oxygen uptake test which are useful in activated sludge operations. The two applications are called fed and unfed samples.
32. The fed sample is a mixture of primary clarifier effluent and RAS or return activated sludge. Oxygen Uptake Analysis on a fed sample is used to assess biological activity at the start of the aeration process.
33. The unfed sample is a mixture of unchlorinated secondary clarifier effluent and return activated sludge. Oxygen Uptake Analysis of an unfed sample is used to assess biological activity after aeration and settling.
34. So, to run oxygen uptake on these two mixed samples you will need to collect samples of primary effluent, return activated sludge, and unchlorinated secondary effluent.
35. For both the fed and unfed samples the objective is to create a mixed sample where the solids concentration in the mixed sample is the same as the aeration tank solids concentration.
36. The desired concentration is achieved by diluting a calculated volume of RAS with either the primary or secondary effluent.

37. In order to calculate the volume of RAS needed to make the dilution find the ATC or aeration tank concentration and the RSC or return sludge concentration. In both cases, the concentrations are found by the centrifuge test and expressed as percent.
38. Divide the ATC by the RSC and multiply by 300 to find the volume of return activated sludge needed. The 300 is the volume of the BOD bottle.
39. After the volume of RAS has been calculated mix the RAS sample and, using a graduated cylinder, transfer the calculated volume into a BOD bottle.
40. Now, if you are running a fed sample fill the BOD bottle with primary effluent. However, if you're running an unfed sample fill the BOD bottle with unchlorinated secondary effluent.
41. Then mix and aerate by pouring back and forth as before and proceed with the test as with a grab sample.
42. After running the oxygen uptake test on a fed or unfed sample check the concentration of the sample you've prepared in the BOD bottle. Do this by remixing the sample in the BOD bottle, pouring some of it into a centrifuge tube and running the centrifuge test. If the concentration varies more than one or two tenths of a percent from the ATC the oxygen uptake data may not be valid.
43. Now let's return to the data and calculations. Whichever type of sample you have used plot the oxygen values against time for each minute on a piece of graph paper.
44. A straight line is drawn so that it passes through the greatest number of plotted points. The line plotted is the curve of "best fit" in each of these examples. This line may not pass through all of the points on the graph. A lag may be observed at the start. Ignore this section when fitting the straight line.
45. Next the slope of the line must be calculated. First select two points on the plotted line, one near the start and one near the finish. The slope of the line is the change in oxygen divided by the change in time.
46. To do this first determine the change in oxygen concentration. Determine the oxygen concentration at points A and B. Subtract the oxygen concentration read at "B" from the concentration at "A". In other words, take the lower value from the higher one. This value is in milligrams per liter.
47. Next, determine the change in time. From the same two points on the plotted line, read down to find the time for those points. Subtract the time at point "C" from the time at point "D". This time interval is in minutes.

48. The slope of the line is then found by dividing the change in oxygen concentration (A - B) by the change in time (D - C).
49. Since the slope of the line compares oxygen concentration to time in minutes, we must convert time to hours in order to express the ratio as Oxygen Uptake Rate. Oxygen Uptake Rate, usually called OUR, is expressed in mg/l/hr.
50. The specific uptake rate is calculated from the data obtained in the oxygen uptake rate test and from the volatile suspended solids test.
51. Specific uptake rate equals the oxygen uptake rate divided by the mg/l of volatile suspended solids.
52. During this lesson we have described the equipment necessary to perform this test.
53. We have described the basic procedures of sample site selection, measurement of temperature and oxygen concentration at the sample site, and sample collection.
54. The Oxygen Uptake Rate test procedure was described. This procedure includes mixing the sample, transferring to a BOD bottle, and observing DO changes over a period of time.
55. And finally, the test produces two useful operational values: oxygen uptake rate (OUR) and specific uptake rate (SUR).
56. Oxygen uptake rate is used when information is needed to show the rate of biological activity in a system at a given time.
57. Specific uptake rate is used if comparisons of two systems are needed or if a single system is to be charted over a period of time.
58. The specific uptake rate can be very useful in successfully operating an activated sludge system. Let's discuss several of these applications.
59. Stabilization of waste after aeration is determined by running oxygen uptake rate on a grab sample of activated sludge.
60. Toxic or high organic loads can often be detected before severe deterioration of effluent quality occurs. Changes in the specific uptake rate on effluent samples will indicate changes in loading.
61. Feed acceptability can be determined by testing once per day at peak flow. Small plants with no industry may be able to test weekly.
62. The effect of toxic wastes can be determined by running the specific uptake rate. By adding the suspected toxic waste to a fed sample in proportions that might enter the plant, it is possible to predict the impact on the aeration basin.

63. Similarly the impact of non-toxic waste such as meat processors, breweries or canneries, can be assessed.
64. A stabilization test can be used to estimate biological activity in mixed liquor during the aeration cycle. This test is a series of oxygen uptake tests over a period of time. A fed sample is set up and oxygen uptake rates determined every 15 minutes for 2 to 5 hours or until the uptake rate levels off.
65. Minimum stabilization time is estimated using the stabilization test. For example, should one or two aeration basins be used? The procedure for the stabilization time test is included in the supplementary student materials.
66. Specific uptake rates determined on unchlorinated final effluent can be used to estimate final effluent BOD.
67. Specific uptake rates on aerobically digested sludge can be used to measure the stability of sludge prior to land application.
68. The oxygen uptake rate test is a valuable tool in the operation of aerobic systems. By using this test the operator can monitor current status, predict changes, estimate potential impacts, and assess stabilization.

APPENDIX A


Use overhead #1 to explain the calculation of the slope of the oxygen concentration vs. time curve. Construct overhead #1 as follows:


1. Make transparencies of all figures.
2. Attach the basic concentration vs. time curve (page Ou-10) to the back of an overhead frame.
3. Overlay the transparency page Ou-11 on the first so that the guides fall on the axis and times 1 and 2 are on the straight slope line.
4. Tape the left edge to the overhead frame.
5. Overlay the transparency page Ou-12 on the first two so that the slope calculations are below the plotted data.
6. Tape the right edge to the overhead frame.

First, show the O_2 concentration vs. time, min. plotted data and discuss how the line of "best fit" is drawn. Then, flip over the next transparency and show the selection of time 1 and time 2. These data points should be far enough apart to allow a drop of at least 1 mg/l in O_2 concentration.

Finally, flip over the last transparency and go through the calculation of slope. Point out that the slope is calculated as mg/l/min.

O₂ conc, mg/l





$$\begin{aligned} \text{Slope} &= \frac{O_2 \text{ (time 1)} - O_2 \text{ (time 2)}}{\text{time 2} - \text{time 1}} = \frac{7.5 - 3.5}{25 - 10} = \frac{4.0 \text{ mg/l}}{15 \text{ min.}} \\ &= \frac{0.27 \text{ mg/l}}{\text{min.}} \end{aligned}$$

APPENDIX B

For use with overhead #2 on the next page.

Since the slope of the line plotted from the data of oxygen concentration vs. time is expressed as mg/l/min. and uptake rates are expressed in mg/l/hr we must convert minutes to hours. - A simple conversion formula is:

$$\text{O.U.R.} = \text{Slope in mg/l/min.} \times 60 \text{ min./hr.}$$

$$\text{O.U.R.} = \text{mg/l/hr}$$

Oxygen Uptake Rate (OUR)

$$\text{OUR} = \frac{\text{mg/l}}{\text{hr.}}$$

$$= \text{slope, } \frac{\text{mg/l}}{\text{min.}} \times \frac{60 \text{ min.}}{\text{hr.}}$$


APPENDIX C

Use overheads #3 and #4 to discuss specific uptake rate.

Overhead #3 illustrated the relationship between oxygen uptake rate and volatile suspended solids data. Overhead #3 also shows the formula used to calculate SUR.

Overhead #4 gives a sample SUR problem and the solution.

SPECIFIC UPTAKE RATE (SUR)

$$\text{SUR} = \frac{\text{Uptake Rate}}{\text{MLVSS}} = \frac{\text{UR} \times 1000}{\text{MLVSS}}$$


SAMPLE PROBLEM:

Find SUR

$$\text{If: } UR = 24 \text{ mg/l/hr}$$

$$MLVSS = 2400 \text{ mg/l}$$

$$SUR = \frac{UR \times 1000}{MLVSS} = \frac{24 \times 1000}{2400}$$

$$= 10 \text{ mg O}_2/\text{l/hr/g MLVSS}$$


APPENDIX D

Use overhead #5 to show the formula to calculate ml returned activated sludge (RAS) required to mix a fed or unfed sample. Point out that the aeration tank concentration (ATC) are expressed in percent by centrifuge spin. Bottle volume is 300 ml if a standard BOD bottle is used.

$$\text{Vol. of RAS}_{\text{ml}} = \frac{\text{ATC}}{\text{RSC}} \times \text{Bottle Vol., ml}$$

APPENDIX E

Use overhead #6 to explain the Stabilization Time test. By plotting OUR data determined on a sample over a period of time, a curve similar to that on this overhead is obtained. As the curve levels out at a low OUR value, the sample is less active biologically and, therefore, more stable. The time required to reach that point can be read directly from the curve.



OXYGEN UPTAKE TEST

WORKSHEET

Directions: Place an "X" by the best answer. There is only one best answer for each question.

1. The rate at which oxygen is used in an aquatic system to break down organics is called _____.
 - a) _____ metabolism
 - b) _____ oxygen profile analysis
 - c) _____ decomposition
 - d) X oxygen uptake rate
 - e) _____ None of the above.

2. The oxygen uptake rate is based upon a series of _____ that are taken over a period of time.
 - a) _____ pH tests
 - b) _____ solids tests
 - c) X oxygen tests
 - d) _____ alkalinity
 - e) _____ temperature readings

3. Calculations combining volatile suspended solids (VSS) data and oxygen uptake rates yield _____.
 - a) _____ oxygen profiles
 - b) _____ VSS
 - c) _____ alkalinity data
 - d) _____ CO₂ data
 - e) X specific uptake rates


4. The amount of oxygen used by one gram of organic material in one hour is defined as the _____.
 - a) _____ pH
 - b) _____ alkalinity
 - c) _____ oxygen uptake rate
 - d) X specific uptake rate
 - e) _____ None of the above.

5. Equipment needed for the oxygen uptake test includes _____.
- a) _____ pH meter, turbidimeter and centrifuge
 - b) ☒ DO meter with submersible probe
 - c) _____ burette, pipets, thermometer
 - d) _____ thermometer, turbidimeter, pH meter
 - e) _____ None of the above.
6. If S.U.R. are to be obtained, equipment for the _____ test is also necessary.
- a) ☒ VSS
 - b) _____ pH measurement
 - c) _____ alkalinity test
 - d) _____ hardness test
 - e) _____ None of the above.
7. Oxygen uptake rates can be used in operational control of activated sludge systems because they show _____.
- a) _____ pH of the system
 - b) _____ alkalinity of the system
 - c) _____ hardness of the system
 - d) _____ temperature of the system
 - e) ☒ organism activity
8. A series of oxygen uptake tests run over a period of time to check biological activity in the mixed liquor is often called a _____.
- a) _____ uptake test
 - b) _____ specific uptake test
 - c) _____ pH test
 - d) ☒ stabilization test
 - e) _____ solids analysis

9. Information gathered from the stabilization test can be used to estimate _____.
a) ☒ feed rates
b) _____ pH of sludge
c) _____ alkalinity of sludge
d) _____ solids concentration of sludge
e) _____ buffering capacity of sludge
10. S.U.R. on aerobically digested sludge can be used to measure _____ prior to land application.
a) ☒ sludge stability
b) _____ pH of sludge
c) _____ alkalinity of sludge
d) _____ solids concentration of sludge
e) _____ buffering capacity of sludge
11. By mixing primary clarifier effluent and RAS what type of sample is prepared?
a) _____ unfed
b) ☒ fed
c) _____ proportional composite
d) _____ grab
12. If the ATC was 3% and the RSC was 12% what volume of RAS would be required to make a 300 ml unfed sample?
a) _____ 150 ml
b) _____ 1200 ml
c) _____ 9 ml
d) ☒ 75

13. Given the following data plot oxygen concentration vs. time.

<u>TIME</u>	<u>OXYGEN CONCENTRATION</u>
0 minutes	14 mg/l
5 minutes	14 mg/l
10 minutes	10 mg/l
15 minutes	8 mg/l
20 minutes	5 mg/l
25 minutes	4 mg/l



14. Using the data on problem 13 calculate the slope of the line.

Use:

$$\text{SLOPE} = \frac{(\text{Oxygen conc. at time 1}) - (\text{Oxygen conc. at time 2})}{(\text{time 2}) - (\text{time 1})}$$

time 1 = 6 min

time 2 = 18 min

$$\text{Slope} = \frac{13 \text{ mg/L} - 6 \text{ mg/L}}{18 \text{ min} - 6 \text{ min}} = \frac{7 \text{ mg/L}}{12 \text{ min}} = 0.58 \text{ mg/L/min}$$

15. Using the information in problem 14 determine the Oxygen Uptake Rate.

$$\text{OUR} = \text{Slope} \times 60 \text{ min/hr}$$

$$= 0.58 \text{ mg/L/min} \times 60 \text{ min/hr}$$

$$= 34.8 \text{ mg/L/hr}$$

16. The VSS was determined to be 1100 mg/l in the aeration basin from which our sample was taken. Using this information plus what we have determined in problems 14 and 15 calculate the SUR.

$$\text{SUR} = \frac{\text{U.R.} \times 1000}{\text{VSS}}$$

$$\text{SUR} = \frac{34.8 \text{ mg/L/hr} \times 1000 \text{ mg/g}}{1100 \text{ mg/L}}$$



$$= 31.6 \text{ mg O}_2/\text{L/hr/g of VSS}$$

This L drops out because you're dealing with a 1 liter theoretical volume; i.e. the SUR is the mg/L of oxygen used per hour by 1 gram of Volatile Susp. Solids.

Operational Control Tests for Wastewater Treatment Facilities

Oxygen Uptake

Student Workbook



**Linn-Benton Community College
Albany, Oregon**

OXYGEN UPTAKE

Written By:
John F. Wooley
Linn-Benton Community College
Albany, Oregon

Instructional Design:
Priscilla Hardin
Corvallis, Oregon

Project Management
John W. Carnegie, Ph.D.
Linn-Benton Community College
Albany, Oregon

Project Officer:
Lynn S. Marshall
United States Environmental Protection Agency
National Training and Operational Technology Center
Cincinnati, Ohio

Developed Under:
EPA Grant #900953010
August, 1980

OXYGEN UPTAKE TEST

<u>Subject</u>	<u>Page</u>
Introduction	S-0u-1
Objectives	S-0u-1
Prerequisite Skills	S-0u-1
Resource List	S-0u-2
Oxygen Uptake Test Procedures	S-0u-3
Supplementary Material	
Preparing Fed and Unfed Samples	S-0u-6
Interpretation of Oxygen Uptake Test Results	S-0u-7
Stabilization Test	S-0u-10
Suspended Solids Test	S-0u-12
Volatile Suspended Solids Test	S-0u-16
Oxygen Uptake Test Data Sheets	S-0u-18
Sample Data Sheet	S-0u-20
Procedure Summary	S-0u-21
Worksheet	SW-0u-1

INTRODUCTION

This module on oxygen uptake is intended to give the operator the basic information necessary to obtain reliable data from the test procedure.

The mention of any brand names should not be taken as an endorsement of that material.

This test procedure is intended to be used by individuals who have completed NPDES level 1 laboratory skills training.

OBJECTIVES

Upon completion of this module you should be able to:

1. Describe the purpose of the oxygen uptake test.
2. Describe the purpose of the Specific Uptake Rate calculation.
3. Describe the oxygen uptake test.
4. Describe what samples are mixed to make a fed and unfed sample.
5. Calculate the volume of RAS needed to make a fed and unfed sample.
6. Plot oxygen concentrations vs. time on graph paper.
7. Calculate slope and uptake rate.
8. Calculate specific uptake rate.
9. Perform the test procedure.

PREREQUISITE SKILLS

In addition to the skills listed in the introduction, the following skills are needed for this test:

1. Knowledge of maintenance, calibration, and use of DO meter.
2. Ability to use a timer clock.

RESOURCE LIST

1. Scientific Products
3660 148th Ave., NE
Redmond, WA 98052
(206) 885-4131

DO meter, YSI
Model 57
#G 1670-30
Probe, BOD bottle, YSI
#G 1671-30
Timer, Universal
#C 6522-5-Timer

2. VWR Scientific, Inc.
P.O. Box 13007, Station K
Atlanta, GA 30324
(404) 262-3141

DO meter YSI
Model 57
#52456-210
Probe, Self-stirring, YSI
#52457-001
Timer, Universal
#62317-001

3. Sargent-Welch
1617 East Ball Road
Anaheim, CA 92803
(213) 860-8584

DO meter, YSI
Model 57
#S-38633-20
Probe-BOD, Stirring
#S-38632-42
Clock
#S-19760

Further information on the performance of this test may be found by obtaining the following written material:

1. Activated Sludge Operational Control, by Environmental Technology Department, Linn-Benton Community College, Albany, Oregon 97321.

OXYGEN UPTAKE TEST

INTRODUCTION

Biological waste treatment in the activated sludge process is based on the ability of micro-organisms to utilize dissolved oxygen in breaking down soluble organic substances.

The oxygen uptake test is a means of measuring the respiration rate of the organisms in the activated sludge process. Since it measures the oxygen used in the process, it is a useful tool in the evaluation of process performance, aeration equipment and biodegradability of the waste. So that comparisons can be made between various plants, it is usually expressed as the SUR (specific uptake rate); i.e. the amount of oxygen in mg utilized by one gram of the volatile suspended solids in the activated sludge, in one hour.

EQUIPMENT

1. Dissolved Oxygen Meter with probe adapted to BOD bottle
2. 300 ml BOD bottle
3. Magnetic stirrer and magnetic stirring bar
4. 5 liter sample bottle
5. Timer

PROCEDURE

1. MEASURE AND RECORD DO

Using the dissolved oxygen meter measure and record the DO and temperature at the sample site.

2. COLLECT 5 LITERS OF SAMPLE

3. FILL 300 ml BOD WITH SAMPLE

4. MIX AND AERATE

Place a PVC adapter in the neck of the BOD bottle and then attach a second BOD bottle upside down on the adapter. Mix by transferring sample from one BOD bottle to the other 15 times.

5. PLACE ON STIRRER WITH MAGNETIC STIR BAR6. PLACE DO PROBE IN THE BOTTLE

Place the DO probe in the bottle making sure the stopper provides a good seal and switch on the magnetic stirrer.

7. MEASURE DO

After about one to two minutes record the DO concentration in the bottle every minute for approximately 10-20 minutes. The actual time required depends on the rate of oxygen depletion. Allow sufficient time to get at least 1 mg/l DO difference between start and finish of the test.

8. PLOT OXYGEN DEPLETION ON GRAPH PAPER

Plot the oxygen depletion against time on the graph paper and calculate the uptake rate.

CALCULATIONS

1. DO VALUES TO BE PLOTTED ON GRAPH PAPER

The dissolved oxygen values recorded every minute are plotted on the graph paper.

2. DRAW STRAIGHT LINE THROUGH POINTS

A straight line is then drawn so that it passes through the most number of points.

3. CALCULATE SLOPE

The slope can now be calculated: two points in time are selected through which the line passes. By subtracting the lower DO value from the higher and dividing the answer by the time interval selected, the slope is obtained.

4. CALCULATE UPTAKE RATE

The uptake rate is expressed normally in the units $\text{mg O}_2/\text{l/hr}$ therefore from the slope:

$$\text{Uptake Rate} = \text{mg O}_2/\text{l/min} \times 60 \text{ min/hr}$$

5. CALCULATE SPECIFIC UPTAKE RATE

The Specific Uptake Rate (SUR) can now be calculated:

$$\text{SUR} = \frac{\text{Uptake Rate} \times 1000}{\text{VSS (mg/l)}}$$

e.g., say volatile suspended solids = 2400 mg/l and uptake rate = 24 mg/l/hr

$$\text{SUR} = \frac{24 \times 1000}{2400} = 10 \text{ mg. O}_2/\text{l/hr/g VSS}$$

VSS is normally obtained from the routine daily solids analysis.

PREPARING FED AND UNFED SAMPLES

Definitions:

Fed Samples - A mixture of Return Activated Sludge (RAS) and primary clarifier effluent. Use raw influent if plant does not have a primary clarifier.

Unfed Sample - A mixture of Return Activated Sludge (RAS) and secondary clarifier effluent.

The Goal: To dilute RAS with either primary or secondary effluent so as to approximate the aeration tank concentration (ATC).

Procedure:

1. Determine Volume of RAS Needed

$$\text{Vol. RAS, ml} = \frac{\text{ATC}}{\text{RSC}} \times \text{sample volume needed, ml}$$

Where ATC = aeration tank concentration

RSC = return sludge concentration

Example:

if ATC = 3%

RSC = 15%

volume needed = 300 ml BOD bottle

$$\text{Vol. RAS, ml} = \frac{3}{15} \times 300 = 60 \text{ ml}$$

2. Transfer Calculated RAS Volume to BOD Bottle

3. Fill BOD Bottle With Effluent

Use primary effluent for fed sample. Use secondary effluent for unfed sample.

4. Run Oxygen Uptake Rate

INTERPRETATION OF OXYGEN UPTAKE TEST RESULTS

1. UNFED - OUR's follow the load during the day and week. For mixed liquor concentrations of 2500 - 3500 ml/l. UNFED - OUR should be approximately 0.3 - 0.7 mg DO/l/min.
2. To compare OUR's on various sludges, the Specific Oxygen Uptake Rate (SOUR), a concentration independent value in mg O₂/hr/gm can be determined.
 - A. Calculate OUR in mg O₂/l/hr.
$$\text{OUR} = \text{mg/l/min} \times 60 \text{ min/hr} = \text{mg O}_2/\text{l/hr}.$$
 - B. Divide by VSS to obtain SOUR
$$\text{SOUR} = \frac{\text{mg O}_2/\text{l/hr (OUR)}}{\text{mg/l (VSS)}} \times 1000 \frac{\text{mg}}{\text{gm}}$$
 - C. Example - OUR = 0.7 mg/l/min VSS = 2500 mg/l
$$\text{SOUR} = \frac{0.7 \times 60 \times 1000}{2500} = 16.8 \text{ mg O}_2/\text{hr/gm}$$
 - D. Optimum UNFED - OUR is about 12-20 mg O₂/hr/gm
3. Low UNFED - OUR (< 0.3 mg DO/l/min; < 5 mg O₂/hr/gm)
 - A. Indicates starved, over-oxidized sludge (appropriate value for aerobic digester)
 - B. Fast settling rates
 - C. Pin floc
 - D. Common to extended aeration systems - old sludge
 - E. Corrective Action - Increase wasting, decrease VSS.
4. High UNFED - OUR (> 0.8 mg DO/l/min; > 20 mg O₂/hr/gm)
 - A. Indicates bulky, under-oxidized sludge (young)
 - B. May go septic in clarifier
 - C. Poor settling and compaction

D. Corrective Action - Increase oxidative pressures

- I. Contact or step-feed mode change may be called for.
- II. Flocculant aid may be necessary to achieve settling and compaction.
- III. Monitor DO of return sludge and adjust to allow for maximum settlability without septicity.

5. FED - OUR's follow availability and concentration of the feed. FED samples are more apt to change than UNFED. Measurement can provide time to anticipate likely changes and make corrections. FED - OUR's will likely range from two to five (2 - 5) times the UNFED - OUR (0.6 - 3.5 mg O₂/l/min).

A. After feeding, OUR can be expected to increase relative to UNFED.

B. Plant may impose limit on oxygenation capacity. Most systems should be able to handle FED - OUR's of 2.0 - 2.5 mg/l/min.

I. If not, or if FED-OUR higher, all or any below:

- a) improved mixing may be necessary
- b) step-feeding to distribute load
- c) more or modification of aerators

C. Toxic loads will depress FED relative to UNFED

- I. treatment will suffer
- II. coagulant or powdered activated carbon may help
- III. if repeated, identify problem along collection system
- IV. if feed is suspect, check by using acceptable feed such as dextrose or sucrose to assess low activity
 - a) If OUR increases, "bugs" are not assimilating food
 - b) If OUR does not change, something in waste is toxic to "bugs".

E. A small increase can be due to dilute feed, poor quality feed, sick sludge or unfavorable conditions (e.g. too long clarifier sludge detention time).

6. Load Index (LF - load factor)

- A. Ratio of FED - OUR to UNFED - OUR
- B. Indicates activity before and after feeding

C. Good sludge and acceptable feed increases $LF > 1.0$ due to no depression in FED - OUR

- I. $LF < 1.0$ - inhibitory or toxic load
- II. $LF > 1.0$ but < 2.0 - dilute or stabilized load
- III. $LF > 2.0$ but < 5.0 - acceptable loading
- IV. $LF > 5.0$ - possible O_2 supply problems

STABILIZATION TEST

INTRODUCTION

A stabilization test is a series of oxygen uptake rate tests done over a period of time on an aerated mixture of primary clarifier effluent and return activated sludge. This fed sample reflects the loading on the aeration system and measures sludge activity during the aeration cycle. This test helps the operator determine if adequate aeration time is available, if excessive oxygen demands are being placed on the system and how a new load is affecting the system. A curve illustrating the stabilization process can be drawn.

EQUIPMENT

- 2 Timers
- Magnetic stirrer and stir bars
- 300 ml BOD bottle
- Dissolved oxygen meter w/ probe to fit BOD bottle
- Large sample bottles
- 1 liter graduated cylinder
- Small tank (10 liter minimum)
- Aerator device (filtered compressed air)
- Siphon tube

PROCEDURE

1. DETERMINE O.U.R. ON UNFED SAMPLE.

Run oxygen uptake rate on unfed sample. Mix secondary clarifier effluent and RAS as described in the procedure for preparing fed and unfed samples.

2. DETERMINE VOLUME OF R.A.S. NEEDED.

Prepare at least 6 liters of fed sample. Determine volume of RAS needed by the following formula.

$$\text{RAS, liters} = \frac{\text{ATC}}{\text{RSC}} \times \text{volume needed, liters}$$

Example: ATC = 3%

RSC = 12%

Volume needed = 6 liters

$$\text{RAS, liters} = \frac{3}{12} \times 6 = 1.5 \text{ liters}$$

3. MIX R.A.S. WITH PRIMARY EFFLUENT.

In a small tank mix calculated volume of RAS with primary effluent to bring the volume up to the total desired.

4. AERATE THE FED SAMPLE.

Provide continuous aeration and mixing to the fed sample in the small tank.

5. START TIMING THE AERATION PERIOD.

6. RUN O.U.R. AT TIME ZERO.

At the start ($t = 0$) draw off 300 ml into a BOD bottle and run OUR.

7. RETURN SAMPLE TO TANK

after running OUR.

8. RUN O.U.R. EVERY 15 MINUTES

until the OUR approaches the unfed OUR value.

9. PLOT DATA FOR STABILIZATION CURVE.

Plot time on horizontal (x) axis and OUR on vertical (y) axis. Use standard graph paper.

SUSPENDED SOLIDS

INTRODUCTION

Suspended solids are those solids which can be trapped on a glass fiber filter. By this definition suspended solids will also include settleable solids. The suspended solids test is one of the primary criteria used to evaluate effluent quality. A well-run trickling filter plant should operate below 30 mg/l of suspended solids in the final effluent and an activated sludge plant below 10 mg/l suspended solids in the final effluent.

EQUIPMENT

Gooch filtering crucible, 25 ml size
Glass fiber filter - 2.4 cm in diameter
500 ml glass filter flask
Rubber collar and glass stem for vacuum filtering
Rubber vacuum tubing
Vacuum source, - either mechanical pump or water faucet aspirator vacuum
Forceps
50 ml and 100 ml graduated cylinders
Crucible tongs
Desiccator
Analytical balance - reading to 0.1 mg (0.0001 g)
Furnace, set at $550 \pm 50^{\circ}$ C.
Drying oven, set at 103° C.
Asbestos pad
Asbestos gloves
Plastic wash bottle

PRELIMINARY PROCEDURES

1. CLEAN CRUCIBLE WITH HOT WATER AND DETERGENT.

Rinse the crucible thoroughly with final rinse of distilled water.

2. PLACE GLASS FIBER FILTER IN CRUCIBLE.

Make sure the rough side of the filter is up. The smooth side generally has small grid marks visible. Use forceps to handle filter discs.

3. WASH THE FILTER.

Using a plastic wash bottle with distilled water, wet the filter while applying a gentle vacuum. Use three washes of about 20 ml each.

4. DRY CRUCIBLE AND FILTER

for 1 hour at 103° C. in dry oven.

5. IGNITE CRUCIBLE AND FILTER IN FURNACE

for 15 minutes at 550 ± 50° C. If volatile suspended solids are not to be run, this step may be skipped.

6. PLACE CRUCIBLE AND FILTER IN DESICCATOR.

After they have been cleaned, washed, ignited, and cool, the crucible along with its filter may be stored in the desiccator until needed.

TESTING PROCEDURE

1. REMOVE CRUCIBLE FROM DESICCATOR.

Use crucible tongs. Crucible and filter should remain in desiccator at least 30 minutes.

2. WEIGH CRUCIBLE AND FILTER.

Record the weight of the crucible plus the filter to four decimal places as "crucible plus filter weight."

3. PLACE CRUCIBLE PLUS THE FILTER ON A RUBBER COLLAR.

First place a rubber collar and glass stem into a vacuum filtering flask. Use tongs and/or a piece of toweling to seat the crucible into the collar. Don't touch the crucible with your fingers as oil and salt residue may

be left on the sides of the crucible and would add some weight that would cause error in the test.

4. SEAT GLASS FILTER WITH VACUUM.

Make sure all of the holes in the Gooch crucible are covered. Wet the filter with distilled water using the plastic wash bottle.

5. WITH VACUUM ON, APPLY SAMPLE TO CRUCIBLE.

See note at the end of this procedure regarding sample volumes.

6. RINSE FILTER.

Use distilled water to wash the solids that are clinging to the sidewall of the crucible down onto the glass fiber filter and to remove any soluble solids trapped in the glass fiber filter.

7. PLACE CRUCIBLE AND FILTER IN DRYING OVEN.

Dry the crucible and its contents for 60 minutes at 103° C. in the drying oven. Use tongs and toweling again.

8. REMOVE CRUCIBLE AND FILTER FROM DRYING OVEN.

Cool the crucible to room temperature on an asbestos pad.

9. WEIGH THE CRUCIBLE AND FILTER.

Weigh the crucible plus its contents to four decimal places and record the weight as "crucible plus filter plus sample."

10. SAVE CRUCIBLE AND FILTER AND SAMPLE

for volatile suspended solids determination. If volatile suspended solids are not to be run, discard the filter and clean the crucible.

CALCULATIONS

EXAMPLE: Crucible plus filter plus sample 22.6501 g
 Crucible plus filter 22.6245 g
 Sample 0.0256 g

Suspended Solids, mg/l = $\frac{\text{sample weight, g} \times 1000}{\text{sample volume, l}}$

EXAMPLE: for 100 ml sample

Suspended Solids, mg/l = $\frac{0.0256 \text{ g} \times 1000}{0.1 \text{ l}}$
= 256 mg/l

NOTE: Some operators have found it more convenient to use a 600 ml fritted-glass Buchner funnel, Grade C porosity, and a 9 cm glass fiber filter rather than the Gooch crucible. This alteration allows the filtration of a larger sample volume and thus gives better accuracy.

SUGGESTED SAMPLE SIZE FOR SUSPENDED SOLIDS

<u>TYPE OF SAMPLE</u>	<u>USING GOOCH CRUCIBLE</u>	<u>USING BUCHNER FUNNEL</u>
Raw Sewage	2 to 25 ml	50 to 200 ml
Primary Effluent	50 ml	200 ml
Final Effluent	100 ml.	1000 ml

VOLATILE SUSPENDED SOLIDS

INTRODUCTION

- That portion of the suspended solids which can be burned off at $550 \pm 50^{\circ}$ C. is the volatile suspended solids. This value is considered to represent the organic load on the plant and is used more frequently than Volatile Total Solids.

After the final weighing of the crucible for the suspended solids test, the sample can be ignited to burn off the volatile suspended organics.

EQUIPMENT

Same as for Suspended Solids

PROCEDURE

1. OBTAIN CRUCIBLE PLUS SAMPLE.

The crucible with filtered sample from the suspended solids is used for this test. Even if you are not interested in the suspended solids, the value must be determined in order to calculate volatile suspended solids.

2. PLACE CRUCIBLE PLUS FILTER PLUS SAMPLE IN MUFFLE FURNACE.

Use the asbestos glove and long tongs. Ash the sample for 60 minutes at $500 \pm 50^{\circ}$ C. DO NOT exceed 600° C. Sixty minutes will usually be sufficient to reach a constant weight. If a constant weight can be reached in less time, that is also satisfactory.

3. REMOVE CRUCIBLE FROM FURNACE.

Allow the crucible to cool on an asbestos pad for 15 minutes.

4. PLACE CRUCIBLE IN DESICCATOR.

Use the crucible tongs for this procedure. Leave the crucible in the desiccator for 30 minutes.

5. WEIGH CRUCIBLE ON AN ANALYTICAL BALANCE.

Weigh the crucible as quickly as possible to four decimal places. Record the weight as "crucible plus ash weight."

CALCULATIONS

EXAMPLE: 50 ml sample (0.050 l)

Crucible plus filter plus sample	22.6501 g
Crucible plus ash weight	22.6451 g
Weight of volatile suspended solids	0.0050 g

NOTE: Sample volume is same as that for the suspended solids test.

VOLATILE SUSPENDED SOLIDS

$\text{mg/l} = \frac{\text{weight of volatile suspended solids, g} \times 1000}{\text{sample volume, l}}$

EXAMPLE:

$\text{VOLATILE SUSPENDED SOLIDS, mg/l} = \frac{0.0050 \text{ g} \times 1000}{0.050 \text{ l}}$
 $= 100 \text{ mg/l}$

PERCENT VOLATILE SOLIDS

To calculate the percent volatile suspended solids in the sample, use the following formula:

$\% \text{ VOLATILE SUSPENDED SOLIDS} = \frac{\text{mg/l volatile suspended solids} \times 100}{\text{mg/l suspended solids}}$
 $= \frac{100 \text{ mg/l} \times 100}{256 \text{ mg/l}}$
 $= 39\%$

OXYGEN UPTAKE DATA		DATE _____
Technician _____		Sample No. _____
Sample Point _____		Sample Time _____
Air Temp. _____ Water Temp. _____		Sample Site _____ D.O. _____

Time in Min.	Oxygen Conc. in mg/l	Time in Min.	Oxygen Conc. in mg/l	Time in Min.	Oxygen Conc. in mg/l
1		21		41	
2		22		42	
3		23		43	
4		24		44	
5		25		45	
6		26		46	
7		27		47	
8		28		48	
9		29		49	
10		30		50	
11		31		51	
12		32		52	
13		33		53	
14		34		54	
15		35		55	
16		36		56	
17		37		57	
18		38		58	
19		39		59	
20		40		60	



OXYGEN UPTAKE RATE WORKSHEET

Operator: _____

Date: _____

Aeration Tank (Unfed)					Return Sludge + Influent (Fed)				
Time (min)	DO (mg/l)	Δ DO (mg/l)	Temp °C		Time (min)	DO (mg/l)	Δ DO (mg/l)	Temp °C	
0					0				
1					1				
2					2				
3					3				
4					4				
5					5				
6					6				
7					7				
8					8				
9					9				
10					10				
15					15				
20					20				
30					30				

Sample Source:		Sample Source:	
Time		Time	
Temp		Temp	
pH		RSF	
ATC		ATC	
RSC		RSC	
MLSS		$\frac{ATC}{RSC} \times 300 = \text{Volume of RSC for fed sample}$	
MLVSS			
RSS			
RVSS			
Influent Flow			



SAMPLE DATA SHEET

At Sample Point

OXYGEN UPTAKE DATA				DATE <u>9/20</u>	
Technician <u>JC</u>				Sample No. <u>3</u>	
Sample Point <u>Aer. Basin #1</u>				Sample Time <u>9:30 a</u>	
Air Temp. <u>28°C</u> Water Temp. <u>10°C</u>				Sample Site O.D. <u>B.1</u>	
Time in Min.	Oxygen Conc. in mg/l	Time in Min.	Oxygen Conc. in mg/l	Time in Min.	Oxygen Conc. in mg/l
1	6.7	21		41	
2	5.9	22		42	
3	5.6	23		43	
4	5.2	24		44	
5	4.8	25		45	
6	4.5	26		46	
7	4.2	27		47	
8	3.9	28		48	
9	3.6	29		49	
10	3.3	30		50	
11	3.0	31		51	
12		32		52	
13		33		53	
14		34		54	
15	Unfed Sample	35		55	
16	MLSS = 1500 mg/l	36		56	
17		37		57	
18		38		58	
19		39		59	
20		40		60	

DO values in BOD bottle

At Least 1 mg/l DO drop

Addition Notes

PROCEDURE SUMMARY

PROCEDURE

1. Measure DO and temperature
2. Collect 5 liters of sample
3. Fill BOD bottle
4. Mix and aerate
5. Attach probe on stirrer
6. Measure DO change
7. Plot DO depletion vs. time

CALCULATIONS

$$\text{Slope} = \frac{\text{change in DO, mg/l}}{\text{change in time, min.}}$$

$$\text{Uptake Rate} = \text{slope, mg/l/min} \\ \times 60 \frac{\text{min}}{\text{hour}}$$

$$\text{SUR} = \frac{\text{Uptake Rate} \times 1000}{\text{VSS, mg/l}} \\ = \text{mg O}_2/\text{l/hr}$$

Fed Sample: pri. clar. eff. + RAS

Unfed Sample: sec. clar. eff. + RAS

Vol. RAS needed for 300 ml BOD bottle: $\text{RAS, ml} = \frac{\text{ATC, \%}}{\text{RSC, \%}} \times 300$

Oxygen Uptake Test

The above procedure summary is designed as a laboratory aid. It may be cut out and attached to a 5" X 7" index card for convenient reference at the laboratory bench. To protect the card you may wish to cover it, front and back, with clear, self-adhesive shelf paper or similar clear material.

OXYGEN UPTAKE TEST

WORKSHEET

Directions: Place an "X" by the best answer. There is only one best answer for each question.

1. The rate at which oxygen is used in an aquatic system to break down organics is called _____.
 - a) _____ metabolism
 - b) _____ oxygen profile analysis
 - c) _____ decomposition
 - d) _____ oxygen uptake rate
 - e) _____ None of the above.

2. The oxygen uptake rate is based upon a series of _____ that are taken over a period of time.
 - a) _____ pH tests
 - b) _____ solids tests
 - c) _____ oxygen tests
 - d) _____ alkalinity
 - e) _____ temperature readings

3. Calculations combining volatile suspended solids (VSS) data and oxygen uptake rates yield _____.
 - a) _____ oxygen profiles
 - b) _____ VSS
 - c) _____ alkalinity data
 - d) _____ CO₂ data
 - e) _____ specific uptake rates

4. The amount of oxygen used by one gram of organic material in one hour is defined as the _____.
 - a) _____ pH
 - b) _____ alkalinity
 - c) _____ oxygen uptake rate
 - d) _____ specific uptake rate
 - e) _____ None of the above.

5. Equipment needed for the oxygen uptake test includes _____.
- a) _____ pH meter, turbidimeter and centrifuge
 - b) _____ DO meter with submersible probe
 - c) _____ burette, pipets, thermometer
 - d) _____ thermometer, turbidimeter, pH meter
 - e) _____ None of the above.
6. If S.U.R. are to be obtained, equipment for the _____ test is also necessary.
- a) _____ VSS
 - b) _____ pH measurement
 - c) _____ alkalinity test
 - d) _____ hardness test
 - e) _____ None of the above.
7. Oxygen uptake rates can be used in operational control of activated sludge systems because they show _____.
- a) _____ pH of the system
 - b) _____ alkalinity of the system
 - c) _____ hardness of the system
 - d) _____ temperature of the system
 - e) _____ organism activity
8. A series of oxygen uptake tests run over a period of time to check biological activity in the mixed liquor is often called a _____.
- a) _____ uptake test
 - b) _____ specific uptake test
 - c) _____ pH test
 - d) _____ stabilization test
 - e) _____ solids analysis

9. Information gathered from the stabilization test can be used to estimate _____.
- a) _____ feed rates
 - b) _____ pH of sludge
 - c) _____ alkalinity of sludge
 - d) _____ solids concentration of sludge
 - e) _____ buffering capacity of sludge
10. S.U.R. on aerobically digested sludge can be used to measure _____ prior to land application.
- a) _____ sludge stability
 - b) _____ pH of sludge
 - c) _____ alkalinity of sludge
 - d) _____ solids concentration of sludge
 - e) _____ buffering capacity of sludge
11. By mixing primary clarifier effluent and RAS what type of sample is prepared?
- a) _____ unfed
 - b) _____ fed
 - c) _____ proportional composite
 - d) _____ grab
12. If the ATC was 3% and the RSC was 12% what volume of RAS would be required to make a 300 ml unfed sample?
- a) _____ 150 ml
 - b) _____ 1200 ml
 - c) _____ 9 ml
 - d) _____ 75

14. Using the data on problem 13 calculate the slope of the line.

$$\text{SLOPE} = \frac{(\text{Oxygen conc. at time 1}) \text{ minus } (\text{oxygen conc. at time 2})}{(\text{time 2}) \text{ minus } (\text{time 1})}$$

15. Using the information in problem 14 determine the Oxygen Uptake Rate.

16. The VSS was determined to be 1100 mg/l in the aeration basin from which our sample was taken. Using this information plus what we have determined in problems 14 and 15 calculate the SUR.

$$\text{SUR} = \frac{\text{U.R.} \times 1000}{\text{VSS}}$$